

SETTING UP YOUR CONTROLLER

- 1) Plug the Controller's AC/DC Converter (Power Supply) into an AC wall outlet.
- 2) Plug the Controller's Solenoid (Switch Box) into a second AC wall outlet.
- 3) Plug your Regulator or Doser into the Solenoid.

Do NOT plug the Power Supply into the back side of the Solenoid.

